Instructions for starting the brush-cutter/strimmer

The fuel is two stroke (50:1)

To start

1. Lay the brush-cutter on the ground

2. Squeeze both trigger levers into the handle.

3. Slide the switch to START position, remove the pressure on trigger levers.

4. If the engine is cold move the choke lever to closed. If the engine is warm no need to choke. 

5. Prime the engine. Push the fuel bulb at least 5 times.

6. Hold the machine firmly; a foot on the bar helps. Slowly pull out the starter rope until you feel it reach the first stop. Then pull briskly and strongly upwards, keeping it as vertical as you can.

7. When the engine fires or after the fifth pull, move the choke shutter lever to open the choke  or allow engine to warm up

8. Pull the starter rope again. The engine should fire.

9. As soon as the engine is running, briefly touch the throttle trigger. The switch will move into the operating position. The engine idles. The tool stops rotating.

To stop Slide the switch to STOP

To release more cord – Run at full revs and tap the cutting head on a hard surface. More cord should be released.