Instructions for starting the Hayter 56 mower (Container)

The fuel is E5 petrol

1. Push the throttle lever to choke position (the rabbit).
2. Prime the engine (bulb at front, 3-5 presses)
3. Hold in safety bar
4. Pull starter rope until engine starts.
5. Adjust engine speed from choke position.
6. Select cut height, handle left hand side
7. Raise second bar to drive the mower.

To Stop release the safety handle