Instructions for starting the Hayter mower (shed east track)

The fuel is E5 petrol.

1. Turn on the fuel. On the engine, right hand side. Turn anticlockwise.

2. Push the throttle lever to choke position (the rabbit)

3. Pull starter rope until engine starts.

4. Adjust the engine speed once engine has started

5. Adjust the cut height by twist large black knob

6. To drive forward, hold the drive bar onto the main hand bar.

Stop the engine with the throttle lever.

Turn off fuel when finished (turn clockwise)